



# TWO DOOR TOP LOAD PORTABLE KENNEL Assembly Instructions

Item # 5310341



**A** Carrier Top (X1)



**B** Carrier Base (X1)



**C** Bolts (X4)



**D** Nuts (X4)



**E** Side Clips (X4)



**F** Door (X1)

## Tools Required:



Phillips head  
screwdriver


### Step 1

Turn base (B) upside down in order to attach the side clips (E) to the side grooves. Hold the hinge (inside of the clip) to line up with the grooves on the base. On the side clips, the interior hook latches should face down (these connect to the top later).



### Step 2

Push the hinge bar of the side clip into the base's groove until you hear the 'click' to secure it.



### Step 3

Attach all 4 side clips (E) onto the base (B).



### Step 4

Turn base over on its correct side. Put the door (F) into the base's two front holes. Lock can go on either left or right side.



### Step 5

Place carrier top (A) over the door (F) fitting door's top bar ends into the carrier top's holes. Line up the top to the base (B).



### Step 6

Pull clips into the latch to secure top and bottom panels.



### Step 7

Connect the bolts (C) and the nuts (D) in the 4 corner holes. Insert the bolts from the top of the assembly. Attach nuts from underneath. Ensure each nut is fully tightened.



If you are not satisfied with this product, return it with your valid proof of purchase for a refund. Conditions apply. See store or PetSmart.com for details.

For more information about Whisker City® products, please call 1-888-839-9638.

Dist. by/par: Pacific Coast Distributing, Inc., 19601 N. 27th Ave., Phoenix, AZ USA 85027

WC-19-500774

# Assembly Instructions FOR TABLE KENNEL TWO DOOR TOP LOAD



Item # 2310341



**Step 1:** Turn base over on its correct side. Put the door (P) into the base's two front holes. Lock can go on either left or right side.

**Step 2:** Push the hinge part of the side clip into the base's side clip. You hear the click to ensure it.

**Step 3:** Turn base (B) upside down in order to attach the side clip (E) to the side. Hold the hinge (heads of the side clip) with the groove on the base. On the other side, the interior hook should be at the bottom (there's a notch in the top later).



**Step 4:** Place corner top (F) on the door. (F) fitting door's top hole. Insert the corner top's hole into the base (B) top to the base (B).

**Step 5:** Put clip into the latch to secure against bottom panel.

**Step 6:** Insert the bolts (C) and the nuts (D) in the corner holes. Insert the bolts from the top to the base. Attach nuts from underneath. Tighten each nut in the tightened.



© 2003 TINAKI CITY. All rights reserved. This manual is the property of TINAKI CITY. It is to be used only for the purpose of assembling the product. It is not to be reproduced or distributed without the written permission of TINAKI CITY.